

48 9114

V01


48 9254

V02,V03

49 2449

V04,V05,V06

V07




26 2732

V01

41 8395

V02,V03,V04

V05,V06,V07



26 2730



41 8396

36 2893



43 1504

V01,V02,V03

36 3160

16 4516


V01,V02

41 6859

V03,V04

V05,V06

V07




18 4233


18 7478



18 4045



18 4057



Mat. - Nr. - Konstante  
3740 . . . . .

1) 18 8165

2) 18 8171

3) 18 8160


V01,V02,V03,V04


V05

42 5190

V06,V07

- 1) 35 3489
- 2) 36 6184
- 3) 36 6185 (kpl)
- 4) 41 7587
- 5) 41 7588





Mat. – Nr. – Konstante  
3740 . . . . .  
Gebrauchsanweisung  
58 6212  
(FR,ES,EN)


- 1) 41 7587
- 2) 43 1499
- 3) 26 8009
- 4) 41 7579
- 5) 26 7357
- 6) 26 7359
- 7) 26 7356
- 8) 17 3897
- 9) 17 3898
- 10) 17 3896
- 11) 18 4302
- 12) 16 8053
- 13) 41 6914  
V01,V02,V03
- 14) 43 1502
- 15) 43 1503
- 16) 42 3351  
V04,V05
- 17) 42 3352  
V04,V05,V06,V07
- 18) 42 3353  
V04,V05,V06,V07
- 19) 42 3354  
V04,V05,V06,V07


1) 48 8843

V01,V02,V03,V04

49 3152

V05,V06,V07





Mat. – Nr. – Konstante  
3740 . . . . .

- 1) 16 9339
- 2) 17 3894
- 3) 17 3895
- 4) 26 7950
- 5) 26 7951
- 6) 26 7949
- 7) 35 7810
- 8) 35 7811
- 9) 35 7808
- 10) 35 7809

Duesensatz Für:  
EG H/E G20 20mbar  
17 4049

FG G30/31 30mbar  
17 4048

EG H/E G20 20mbar  
(inkl.Bypassdusen)  
41 7597

FG G30/31 30mbar  
(inkl.Bypassdusen)  
41 7837